



Scalable Compact Models for Complex High-Speed Systems

Francesco Ferranti, Tom Dhaene

**Department of Information Technology (INTEC),
Ghent University – IBBT**

WMC: Advanced techniques for electromagnetic-based model generation



OUTLINE



Introduction

Scalable Macromodels

Numerical examples

- Data-driven PMOR
- Model-driven PMOR

Conclusions



OUTLINE



Introduction

Scalable Macromodels


Numerical examples

- Data-driven PMOR
- Model-driven PMOR



Conclusions

Introduction


telecom




electronics




fluid dynamics




chemistry



biomodeling





geology





automotive




Introduction



Adaptive Modeling





Distributed Computing




Configurable infrastructure



Introduction



Adaptive Modeling




Distributed Computing





Introduction



Introduction



Introduction



Introduction



Design process

- **several decisions**
 - materials
 - geometrical dimensions
 - shape
 - constraints
 - space
 - cost
 - performance



Design process




Simulators

- implementation of models
- describe systems behavior
- help designers

Measurements

- post tuning
- verification
- help designers





OUTLINE



Introduction

Scalable Macromodels

Numerical examples

- Data-driven PMOR
- Model-driven PMOR


Conclusions

Scalable macromodels



A typical design process requires

- Multiple simulations (measurements)
 - different design parameters values (e.g. layout features)
 - **design space optimization**
 - **design space exploration**
 - **sensitivity analysis**



Scalable macromodels



A typical design process requires

- Multiple simulations (measurements)
 - computationally expensive (time and memory)




- Can we do better?


- **Yes**
 - **By scalable macromodels**




Scalable macromodels



Scalable macromodels



Scalable macromodels




PMOR concepts

Two design space grids are used in the modeling process


- **estimation grid**
- **validation grid**

Design space





$$g = (g^{(n)})_{n=1}^N$$


Scalable macromodels




Model-driven PMOR




Model-driven PMOR




Model-driven PMOR




Data-driven PMOR



Data-driven PMOR




data-driven PMOR




- ★ accuracy
- ★ efficiency
- ★ stability guaranteed
- ★ passivity guaranteed

Data-driven PMOR



data-driven PMOR





OUTLINE



Introduction

Scalable Macromodels

Numerical examples

- Data-driven PMOR
- Model-driven PMOR

Conclusions



OUTLINE



Introduction


Scalable Macromodels

Numerical examples


- **Data-driven PMOR**
- **Model-driven PMOR**

Conclusions

Data-driven PMOR



data-driven PMOR



Data-driven PMOR example






3D example: Interconnection structure

- Mobile phone application
- 10 lines (20 ports)
- etched ground plane



Parameter	Min	Max
Frequency (f_{req})	0 Hz	20 GHz
Spacing (S)	25 μm	65 μm
Angle (α)	45°	65°




Data-driven PMOR example



- CPU time model **estimation**
- CPU time model **validation**


Design space

Step	CPU time
Estimation	10 h
Validation	6 h



Data-driven PMOR example



Poles



Data-driven PMOR example





Output



Data-driven PMOR example


Output



Data-driven PMOR example




- **Design optimization**
- minimum S , minimum α
- $|S_{13}(s, S, \alpha)| \leq -22$ dB over $[0 - 20]$ GHz



Data-driven PMOR example




- **Design optimization**
- minimum S , minimum α
- $|S_{13}(s, S, \alpha)| \leq -22$ dB over $[0 - 20]$ GHz
- initial values



Data-driven PMOR example



- **Design optimization**
- minimum S , minimum α
- $|S_{13}(s, S, \alpha)| \leq -22$ dB over $[0 - 20]$ GHz
- initial values
- optimal values




Data-driven PMOR example



- **Design optimization**
- minimum S , minimum α
- $|S_{13}(s, S, \alpha)| \leq -22$ dB over $[0 - 20]$ GHz
- initial values
- optimal values

Method	CPU time
EM solver	9 h
Parametric macromodel	37 s





OUTLINE



Introduction


Scalable Macromodels

Numerical examples

- Data-driven PMOR
- Model-driven PMOR

Conclusions

Model-driven PMOR



Model-driven PMOR example




3D example: Spiral inductor


Parameter	Min	Max
Frequency ($freq$)	10 kHz	30 GHz
Horizontal length (L_x)	0.46 mm	0.93 mm
Vertical length (L_y)	0.46 mm	0.93 mm

Original order = 801


Reduced order = 91




3D example: Spiral inductor



$L_y = 0.46 \text{ mm}$



$L_y = 0.93 \text{ mm}$





Model-driven PMOR example



3D example: Spiral inductor

$L_x = 0.63$ mm





OUTLINE



Introduction

Scalable Macromodels

Numerical examples


- Data-driven PMOR
- Model-driven PMOR

Conclusions



Conclusions

telecom


Plot of avg_LQI using ANNModel
(built with 29646 samples)




electronics




fluid dynamics




chemistry




biomodeling






geology



automotive





Conclusions



Configurable infrastructure





Adaptive Modeling




Distributed Computing



Conclusions



Adaptive Modeling



Distributed Computing




Conclusions



Scalable macromodels

Multiple design variables



scalable macromodel

Compact models

Efficient design activities (excellent speed-ups)

- **Multiple simulations (measurements)**
 - **Design space optimization, exploration, sensitivity analysis**

Conclusions



Scalable macromodels

Time-domain simulations

- Non-linear drivers and receivers


Stochastic modeling

- impact of manufacturing tolerances

Models from measurements

- noise to handle

Applications in different domains



Questions

